

MENS

AUSTRALIAN SIZES USA SIZES EUROPEAN SIZES

16 17 51

15 16 50

14 15 49

13 14 48

12 13 47

11 12 46

10 11 45

9 10 43

AUSTRALIAN SIZES USA SIZES EUROPEAN SIZES

10 11 42

9 10 41

8 9 40

7 8 38

6 7 37

5 6 36

4 5 35

8 9 42

7 8 41

6 7 40

5 6 38

4 5 37

3 4 36

LADIES



PREMIUM INDUSTRIAL FOOTWEAR

Join pages at this line ▲

Join pages at this line ▼

## HOW TO CHECK YOUR SHOE SIZE

- 1 Stand up and place your foot on the measuring device with the edge of chart and heel right up against a wall.
- 2 To measure size, select size that is on the line past your largest toe. Repeat this with the other foot.
- 3 Select the size that fits the largest foot.

### IMPORTANT

- Allow for socks.
- This chart is a guide only.
- Once you have selected your size, slip on a shoe to confirm correct fitting.

**PLEASE NOTE:** For extra width choose a half size.

For further information please contact:

### FOOTWEAR INDUSTRIES PTY LTD

A.C.N. 068 608 917

PO Box 2320, Malaga, Western Australia 6944

Phone 08 9209 3322 Fax 08 9209 2488

International Phone 61 8 9209 3322 International Fax 61 8 9209 2488

Email [boots@steelblue.com.au](mailto:boots@steelblue.com.au)


[www.steelblue.com.au](http://www.steelblue.com.au)



SELECTED STYLES ONLY



**PLACE CHART AND HEEL AGAINST WALL HERE**



222mm

To ensure accurate sizing your copy should measure **222mm** from the dotted heel line to the first sizing line.

Fold or cut along dotted line and place this and heel against wall